



Installing Digigram Drivers for the First Time

Broadcast Electronics Tech Note

THE INFORMATION IN THIS ARTICLE APPLIES TO:

Vault2/VaultXPRESS v. 8.23 and higher

SUMMARY

This article describes the steps to install Digigram NP and miXart drivers for the First Time. The sound cards must be installed before installing the drivers.

MORE INFORMATION

INSTALLING THE NEW DIGIGRAM MIXART AND NP RUNTIME 6.02E DRIVERS:

- Digigram sound cards must be installed before installing the NP and miXart drivers.
- Shutdown the PC - Remove the power cord - Remove the cover
- Install the sound card(s) in an available PCI slot
- Put the cover back and connect the power cord
- Turn on the computer
- Once the computer starts-up, the Hardware wizard will start.



- Click **Cancel** on all **Found New Hardware Wizard** windows.
- If running, disable any Anti-Virus protection.
- Install the Digigram Driver using **Setup.exe** from directory <X: >\ Utility\Drivers\Digigram Driver Setup. Where X is the CDROM Unit.
- Click Next to start the installation. **DO NOT** click on the CANCEL button at any time.
- The computer will reboot as soon as the driver is completely installed.
- Reboot once more before installing AudioVAULT software.

For additional information on this topic, please contact Broadcast Electronics Digital Customer Service at 217.224.4700. You can also email specific questions to service@bdcast.com.