



2007+ Daylight Saving Time on AV v8.30+

DSC-02-1010 Rev A, 03/03/08

New procedure: Adjustment of Daylight Saving Time settings.

This document applies to all AudioVAULT Systems if running 8.30 or higher.

For AudioVAULT Systems that are running version 8.30 or higher and have Daylight Saving Time enabled, this setting **MUST BE** a system wide setting, that is, *ALL AudioVAULT computer MUST have DST enabled.*

The Daylight Savings Time setting can be enabled keeping in mind that the 1:00am and the 2:00am hours must not have any updates.

The recommended procedure for spring forward or fall back can then be followed as before.

See documents:

Spring Forward Daylight Saving Time for 2007+ v8.30+.pdf

Fall Back Daylight Saving Time for 2007+ v8.30+.pdf

You could also disable DST system wide and manually do the Time change on a more convenient time.